

## Instructions for Installing Vinyl Trim Molding

To ensure the success of your installation, please follow these important installation steps. Skipping these preparations may result in poor performance of the product. Product is not warranted for failure to install correctly.

1. We recommend a trial fit to ensure proper positioning and fit. Do not remove the adhesive backing during the trial fit
2. Wash the installation area with mild soap and warm water. Be sure to clean any debris from the area.
  - a. For surfaces with heavy oil & grease coverage, follow up with a degreaser or solvent based cleaner afterwards to remove additional stubborn patches.
  - b. For surfaces with heavy dirt & oxidation, gently abrade the surface after cleaning.
3. Dry area with a clean cloth & make sure it is free of all debris and dirt.
4. Prepare a mixture of one-part isopropyl alcohol (IPA) to one-part water or get a several alcohol pads to prep the area.
5. Ensure the area is dry and remove the adhesive protective coating about 1"-2" from the edge
6. Apply the molding to the installation area.
7. Apply pressure evenly over the product as you press onto vehicle surface, ensuring all areas of adhesive has attached to the surface. Ensure that there are no ripples or waves in the molding. These could compromise the integrity of the trim.

## Important Notes and Safety Information

- Extreme weather conditions may affect the installation and performance of the trim.
- Before driving, ensure that the molding is properly secured to the vehicle.
- “Brush-Style” car washes are not recommended with this trim.
- Do not use cleaning solvents of any kind.
- Periodically check all trim for adhesion.