

Instructions for creating System Back Ups

IOM System Backup

Backing Up IOM setup information to a USB Drive.

Up to four different backups can be saved to one USB drive.

Use codes '1200', '1201', '1202', and '1203' to store various configurations.

Insert USB drive into either the Driver's or Passenger's TCP. Enter one of '1200' codes. Select 'Save Setup'. All of your configuration changes made to the IOM will be saved to the USB drive.

If your setup is every changed incorrectly, or you need to send your IOM in for service, you will now have a backup of your setup.

When you want to load a saved setup, enter the same code that you used when you saved it, and then select 'Load Setup'.

Touch Panel Backup

Backing Up Touchscreen Setup information to a USB Drive.

Insert USB drive into either the Driver's or Passenger's Touch panel.

Enter code '1300', '1301', '1302', or '1303'

Select 'Save Setup' to save your screen setup.

To reload your setup, enter the same code that you used to save, but select the 'Load Setup' button.