



- 1) Using the #1 mounting base to mark and drill mounting holes and the 1/4" hole in the desired location.
- 2) With the mounting holes drilled you are ready to install the mounting base (1) with the supplied #8 stainless screws (2).
- 3) Push the coach light wires through the 1/4" hole. Then hook the coach light chrome bezel (3) to the top of the mounting base (1). Push the chrome bezel (3) into the bottom of the mounting base and install the retaining screw (4).
- 4) Connect the red wire to the parking light positive 12 volt wire. Connect the black to vehicle body ground. Turn on the park lights to verify the the coach light is working.
- 5) To ensure that water will not leak into the interior of the vehicle we recommend putting silicone sealant around the around the mounting holes and the wire leads inside the vehicle.

Note: Hooking the positive and negative wires backwards will not damage the LED coach light, but it will not light.