


# Tiffany Coachworks Version 1

Note: With the exception of the CPU LED as indicated below, all LED's are operational only when the car's ignition is on.  
15 seconds after the car's ignition is turned off, all LEDs except for the CPU LED are turned off to conserve battery power



## Top of Box LED's

**WARNING -- ANYTIME THIS LED IS ON, BUSSBAR AND COMONENTS INSIDE BOX ARE ENERGIZED DIRECTLY WITH BATTERY POWER. PULL FUSES UNDER CAR HOOD BEFORE ATTEMPTING TO OPEN OR SERVICE BOX !**